




## **CONSTRUCTION MANUAL**

digital-pinball.com/setup











## **Nintendo Switch ONLY**


On the Switch console menu: Settings -> Handle and Sensor -> Wired Connection for Professional Handle to On.













C. Screen

D. Speaker

E. Speaker Power

**Don't** insert the SD card.



